


# Colour is our nature



## Connecting and configuring the LINEARdrive 100D/180D



A Removing the cover




E Optional: Connecting external control device or network cabling




B Removing the strain reliefs




F Fastening the strain reliefs



C Connecting LED wires




D Connecting power supply wires




G Configuring the LINEARdrive DC

Manual configuration

1. Select mode of operation:



2. Set LED groups:






3. Standalone operation - Colour\*

or

Standalone operation - Show -

or


Networked operation - DMX -




\* The colour menu depends on the LED group settings you have selected in step 2.

Other features

Visual test run



Locking the configuration:



Reset to factory defaults

