

CAL, PMA & West – Temperature Control Accessories

| Brand | RS Article | MPN | Accessory Type | Description | For Use With |
|-------|------------|----------------|-------------------|--|---|
| CAL | 730-010 | 301.610 | Adapter | 1/32 DIN to 1/16 DIN Adapter | CAL 1/32 DIN Controllers |
| CAL | 612-940 | 904.400 | Adapter | 1/16 DIN to 1/8 DIN Adapter | CAL 1/16 DIN Controllers |
| CAL | 612-956 | 904.200 | Adapter | 1/16 DIN to 1/4 DIN Adapter | CAL 1/16 DIN Controllers |
| CAL | 312-1807 | 3C0000200 | Comms Card | RS232 Communication Option Board | CAL 3300 & 93/94/9500 Series Controllers |
| CAL | 312-1813 | 3C0000400 | Comms Card | RS485 Communication Option Board | CAL 3300 & 93/94/9500 Series Controllers |
| West | 257-2002 | M9610-C10 | Output Module | Relay Output Plug-in Module | West N Series Contorllers & Indicators |
| West | 257-2024 | M9610-C21 | Output Module | DC Linear Output Plug-in Module | West N Series Contorllers & Indicators |
| West | 257-2030 | M9610-W03 | Input Module | Digital Input Plug-in Module | West N Series Contorllers & Indicators |
| West | 257-2046 | M9610-W06 | Comms Card | RS485 Communication Option Board - Slot A | West N Series Contorllers & Indicators |
| West | 455-0335 | PA1-W06 | Comms Card | RS485 Communication Option Board - Slot A | West Plus Series Controllers & Indicators |
| West | 538-3120 | PS1-CON | Software | Configuration Software (supplied with cable) | West Plus Series Controllers & Indicators |
| West | 455-0262 | PO1-C10 | Output Module | Relay Output Plug-in Module - Slot 1 only | West Plus Series Controllers & Indicators |
| West | 455-0278 | PO1-C21 | Output Module | Linear Output Plug-in Module - Slot 1 only | West Plus Series Controllers & Indicators |
| West | 455-0290 | PO1-C50 | Output Module | SSR Driver Output Plug-in Module - Slot 1 only | West Plus Series Controllers & Indicators |
| West | 455-0307 | PO2-C10 | Output Module | Relay Output Plug-in Module - Slot 2 or 3 | West Plus Series Controllers & Indicators |
| West | 455-0313 | PO2-C50 | Output Module | SSR Driver Output Plug-in Module - Slot 2 or 3 | West Plus Series Controllers & Indicators |
| West | 455-0329 | PO2-C21 | Output Module | Linear Output Plug-in Module - Slot 2 or 3 | West Plus Series Controllers & Indicators |
| West | 612-5587 | PO2-W09 | Output Module | Dual Relay Output Plug-in Module - Slot 2 or 3 | West Plus Series Controllers & Indicators |
| West | 455-0357 | PA1-W03 | Input Module | Digital Input Plug-in Module - Slot A only | West Plus Series Controllers & Indicators |
| West | 612-5593 | PA1-W04 | Input Module | Basic Remote Setpoint Input Plug-in Module - Slot A only | West Plus Series Controllers & Indicators |
| West | 612-5600 | PB1-W0R | Input Module | Full Remote Setpoint Input Plug-in Module | West Plus Series Controllers & Indicators |
| West | 612-5622 | PO2-W08 | Power Transmitter | 24V dc Transmitter Power supply - Slot A only | West Plus Series Temperature Controllers |
| PMA | 291-5320 | 9407-999-01801 | Software | Engineering Tool Programming Software (ET/KS 94) | PMA KS 94 Temperature Controllers |
| PMA | 736-5098 | 9407-924-05001 | Expansion Module | Current, Logic & Relay Output x4 Expansion Module | PMA KS 94 Temperature Controllers |
| PMA | 736-5105 | 9407-923-00001 | Expansion Module | Relay Output x4 Expansion Module | PMA KS 94 Temperature Controllers |
| PMA | 736-5064 | 9407-999-11011 | Software | BlueControl Expert Programming Software | PMA KS40/50/90-1 Temperature Controllers |
| PMA | 736-5073 | 9407-999-11001 | Software | BlueControl Basic Programming Software | PMA KS40/50/90-1 Temperature Controllers |
| PMA | 736-5076 | 9407-999-09101 | Software | BlueControl Basic Programming Software | PMA KS8XX Temperature Controllers |
| PMA | 736 5082 | 9407 998 00003 | Cable | USB / TTL Adapter Cable | PMA KS Temperature Controllers |